

Zoiper SIP VOIP Softphone



Configuration Guide




<https://play.google.com/store/apps/details?id=com.zoiper.android.app&hl=en>

Launch the Zoiper softphone client and click Agree & Continue



Terms & Conditions

Tap "Agree & Continue" to accept the Zoiper [Standard terms and conditions](#) and [Privacy Policy](#)



Agree & Continue





From your account setup notification email, enter your ATA Username, and ATA Password in the corresponding fields below.



Username @ PBX/VoIP provider

Password



Create an account


Providers list



Login with
a QR code



Once you have finished entering the ATA Username and ATA Password select
“Create an account”



Account setup


Username @ PBX/VoIP provider

Password

For example K23Rdw32

Create an account

Enter the SIP Server Address (Domain / Proxy) provided to you in your account setup notification email.



Account setup

Fill in your hostname and select your provider from the list


hostname or provider

This could be called 'Domain', 'SIP Server', 'Registrar' or 'SIP Proxy'. For example 'sip.example.com' or '123.21.123.32:5060'.

Or you can just search for the name of your provider. May be we know the settings.

Next

Click "Skip" as VoIP Much does not require these settings!




Account setup


My provider/PBX requires an authentication username or outbound proxy

Authentication username

Outbound proxy


 **Skip**

Zoiper will use SIP TCP by default. Once a configuration is found select “Finish”



The check mark at the top left of your status bar will indicate a successful registration. If you are not able to register, try restarting Zoiper and verify your device is connected to WiFi with a strong connection. If you continue to have registration issues please call us for support!

1-855-711-VOIP (8647)



Be sure to check your WiFi is on, and with a strong connection.

